

The LINKSYS logo is positioned in the top right corner of the page. It consists of the word "LINKSYS" in a bold, white, sans-serif font, with a small trademark symbol (TM) to its upper right. The background of the entire page is a solid blue color with decorative white curved lines on the left and bottom.

## User Guide

Linksys Network  
Video Recorder  
LNR0208C

# Table of Contents

---

<b>Introduction</b> . . . . .	1	Data Backup. . . . .	36
<b>Hardware Description</b> . . . . .	1	Device Information . . . . .	36
<b>LED Indicators Status</b> . . . . .	2	System Upgrade . . . . .	37
<b>How to Access Web Configuration</b> . . . . .	2	Date & Time . . . . .	37
<b>Quick Configuration</b> . . . . .	3	Buzzer . . . . .	38
Start Quick Configuration . . . . .	3	Reboot & Shutdown. . . . .	38
<b>Live View</b> . . . . .	6	<b>Specification</b> . . . . .	39
<b>Playback</b> . . . . .	12		
<b>Configuration</b> . . . . .	21		
Camera Settings . . . . .	21		
Video Settings . . . . .	23		
Camera Status . . . . .	23		
Recording Settings . . . . .	23		
Event & Action Management . . . . .	25		
E-Mail Settings . . . . .	28		
Disk Management . . . . .	29		
File System Management . . . . .	30		
File Sharing Service . . . . .	30		
Network Setup . . . . .	31		
Network Management . . . . .	32		
DDNS . . . . .	32		
User Management. . . . .	32		
Log System . . . . .	33		
Back Up and Restore . . . . .	35		

# Introduction

## Before You Use This Product

Verify that all the accessories listed on the Package Contents section of the Quick Installation Guide are included. Before installing your NVR, please read the instructions in the Quick Installation Guide to avoid misuse. Follow the instructions in the Hard Disk Installation section of the Quick Installation Guide to avoid damages due to faulty installation.

### NOTE

LiveView and Playback features are **NOT** compatible with Mac OS X.

## Hardware Description



1. LED indicators: LAN, eSATA, HDD1, HDD2
2. Power button
3. USB BACKUP button - Auto video backup
4. USB 2.0 port (For USB storage drive)
5. HDD1
6. HDD2
7. Gigabit LAN
8. USB 2.0 x 2 (Reserved for future use)  
Top to bottom: Vcc5V, GND, DI-1, DI-2, DI-3, DI-4, DO-1, DO-2
9. eSATA x 2
10. DI/DO (4 in 2 out)
11. Reset button
12. Power connector
13. Kensington security slot

## LED Indicators Status



### LEDs on Front Panel

LED	Color & Status	Indicate
LAN	Off	LAN Link is not established
	Orange solid	LAN Link is established
	Orange blinking	LAN is being accessed
eSATA	Off	No data transmission
	Orange blinking	The eSATA device is being accessed
HDD	Off	Hard disk drive is not detected
	Green solid	Hard disk drive is ready to be accessed
	Green blinking	Hard disk drive data is being accessed
	Red solid	Hard disk drive crashed
Power	Off	Power off
	Green solid	Power on
USB Backup	Off	USB device is not detected
	Blue solid	USB device is ready
	Blue blinking	NVR data is being copied to the USB device
	Red solid	Backup error

### LEDs on RJ-45 Port on Rear Panel

LED	Position	Status	Indicate
LAN	Link/Activity (Right LED)	Off	LAN Link is not established
		Yellow solid	LAN Link is established
		Yellow blinking	LAN is being accessed
LAN	Speed (Left LED)	Off	10M/100Mbps connection or no connection
		Orange solid	1000Mbps connection

#### NOTE

- USB BACKUP will beep and begin after pressing BACKUP button for three seconds.
- To turn off your NVR, press the power button for at least three seconds.
- To turn on your NVR, press the power button for at least three seconds.

## How to Access Web Configuration

1. To access the NVR's Web Configuration, open a web browser and enter the IP address of the NVR.

#### NOTE

- If you don't have a DHCP server in the network, the default NVR IP address is **192.168.1.253**.



2. Enter username and password. The default username and password are "admin" and "admin."
3. Allow ActiveX Control or plugin to be installed on your computer if prompted.

**NOTE**

LiveView and Playback features are NOT compatible with Mac OS X.

## Quick Configuration

The first time you log in, the system will direct you through Quick Configuration, or you can click the Wizard icon to launch the Quick Installation.



## Start Quick Configuration

1. The wizard will describe the five steps for configuration. Click **Start**.



- 2) Configure the NVR's network settings to allow your NVR to work properly within your network. After you enter all the information, click **Next**.
  - **Obtain an IP address automatically** - If this option is selected, your NVR will be assigned a dynamic IP address by a DHCP server (such as a router) once the NVR connects to the network.

- **Specify an IP address** - If there is no DHCP server, the default IP address is 192.168.1.253. That address should work in most network environments. You can change the IP address on this page. You SHOULD change the IP address if you have more than one NVR in the same LAN.



- 3) Configure your UPnP settings and device password. Click **Next**.

**UPnP Settings** - Universal Plug and Play (UPnP) simplifies the process of adding a NVR to a local area network. Once connected to a LAN, the NVR will automatically appear on the Windows network. Enable UPnP and give the device a name.

**Password Settings** - You should change the password from the default "admin." Enter a new password in the New Password field and enter it again in Retype Password field.

- 4) Configure your device's date and time. You can have the NVR automatically set date and time with NTP server or you can configure it manually. If you want the NVR to automatically set date the time, select the Time Zone tab and choose the time zone of your area. Click **Next**.



**NOTE**

Verifying and adjusting current local time and daylight saving time will help you avoid the following errors:

- Incorrect display time for playback videos.
- Inconsistent display time of event logs and when they actually occur.


5) If no hard disk drives are installed in your NVR, the page will show "Disk doesn't exist." Once a hard disk drive is installed, the *Disk Information* tab will show the details about that device and allow you to create a new RAID disk. After you enter all information, click.




6) Disk Information provides details of the hard disk drive: Slot Number, HDD Model, Serial No., Capacity and Status. After your disk is created, click **Next**.




a) Click *Create* to enter the *Create New RAID Disk* window. Select the hard disk drive in the Free HDDs field.




b) The selected hard disk drive will be marked in blue. Click  $\gg$  to move the hard disk drive into the Assigned HDDs field.



- c) The selected hard disk drive in Assigned HDDs field will be marked in blue.



- d) You can choose from four types of disk configuration. Choose a disk configuration and click **Apply**.




<b>Big Drive (Linear)</b>	Big Drive is a collection of hard disk drives and does not provide any RAID protection. The data are written to the disks continuously.
<b>Performance (RAID0)</b>	RAID0 combines two or more hard disk drives to function as one larger volume. Data are written to the hard disk drives without any parity information. Total storage capacity is the sum of all hard disk drives.
<b>Fault Tolerant (RAID1)</b>	A RAID1 array requires two hard disk drives. RAID1 provides disk mirroring by duplicating the data between two hard disk drives.
<b>Fault Tolerant (RAID5)</b>	A RAID5 array requires a three or more hard disk drives. Data are striped in all hard drives in a RAID5 array, and parity information is stored in each drive. If a hard disk drive fails, the array enters degraded mode. The data can be rebuilt from other member drives after installing a new drive to replace the failed one.


- e) Configuration progress is tracked in the *Disk Information* window. When formatting progress reaches 100%, configuration mode switches to “create swap.”

**NOTE**


Don't turn off the server or unplug any hard drives when RAID Disk configuration is in process.



- f) When progress reads, "none," the RAID disk configuration is complete. After the RAID disk is created, RAID Disk List shows details about the disk: RAID Name, RAID type, Capacity, Status, Action State, Background Activity, Estimated Time and Progress.



- 7) You can add camera in *Camera Settings*. After your camera is added, click **Next**.
- 8) The window will show the completed status. You can click **Back** to return to the previous steps to modify the configuration or click **Start Live View** to complete quick configuration and start monitoring.







## LiveView

When Quick Configuration is complete, NVR will guide you to live view. You can view a live video stream from your network camera via LAN, and monitor the stream remotely.



### NOTE

LiveView and Playback features are **NOT** compatible with Mac OS X.



Mode	Description
	<b>Wizard</b> Start Quick Configuration.
	<b>LiveView</b> Control the monitoring instantaneously.
	<b>Playback</b> Play and export recorded video files.
	<b>Configuration</b> Configure network camera, recording & event, disk management, network, management and system.











	<p><b>Help</b> Get technical support from Linksys.</p>
	<p><b>logout</b> Leave NVR.</p>

**Main Functions**


















**Disk and CPU loading indicator** - View disk and CPU loading directly without entering the Configuration page. Disk and CPU indicator is blue when loading is 70% or less, and red when it gets higher than 70%. RAID type and video configuration settings, including resolution, FPS and video quality, can influence CPU loading.



Icon	Description
	<p><b>Snapshot</b> To save still photos. The image will display in a pop-up window.</p>  <p><b>Clipboard</b> - Copy the image to device's temporary memory. You can paste the image into a graphics program such as Paint for advanced editing. <b>Save</b> - Save image to default path. <b>Cancel</b> - Cancel snapshot.</p>
	<p><b>Digital zoom out/ in</b> Select a channel to enable digital zoom function</p>
	<p><b>Drop</b> Drop the camera from LiveView</p>
	<p><b>Drop all</b> Drop all cameras from LiveView</p>
	<p><b>Add all</b> Add all cameras to LiveView</p>
	<p><b>Camera information</b> Camera name, IP address, bit rate, and status</p>

## Display mode

Click the icon of display mode to select how many screens you want to monitor. When you click a display mode its icon will turn blue.

Icon	Description
	Full Screen
	1 screen
	4 screen
	9 screen
	10 screen
	12 screen
	16 screen
	20 screen
	25 /30/ 36/49 screen
	5+1 screen
	7+1 screen
	12+1 screen
	Sequential mode Click  to choose the page of Liveview. In Options  , set the sequential interval (in seconds) for display mode.

## Event Log Icon



Event Log notifies users immediately upon motion detection. When motion is detected, the icon will start blinking. Once the icon is blinking, click the button and a pop-up window will display the list of events and the icon will stop blinking.




You can enable the remote Web browser to sound an alarm when motion is detected.



## Option Icon



- General**



**Automatically reorder LiveView windows** - Rearrange video in order without blank grid when dropping video from LiveView.

**Resize all videos at the same time** - Right-click on the video to set all live videos screen to either original size or fit size.




**Highlight video window when event is triggered** - A warning frame will pop out on the channel when an event is triggered.

**Enable Alert Sound** - The remote web browser will sound an alarm when motion is detected.


- Multi-Server**

To save the Multi-Server information in LiveView page.



- Sequential Mode Setting**

Set the interval (in seconds) for sequential mode.



- **Joystick**

Manipulate PTZ camera with a USB joystick. Once you apply the Joystick function, the PTZ icon in status bar indicates joystick enabled.



## PTZ Control Panel

If your network camera supports PTZ function, use the control panel to adjust the viewing angle. The following functions are available depending on the camera models.

Icon	Description
	<p><b>PTZ panel</b></p> <p>PTZ allows you to monitor large areas with a single network camera. Pan, tilt, and zoom functions can be controlled remotely. If device supports PTZ control, click on the arrows to pan and/or tilt the camera. Clicking the house icon returns the camera to its original monitoring position.</p>
	<p><b>Preset positions</b></p> <p>Select from your camera's preset positions.</p>
	<p><b>Optical zoom in/out</b></p> <p>Adjust the PTZ camera to zoom out or zoom in.</p>
	<p><b>Schedule for PTZ</b></p> <p>Set camera preset position.</p> <p>It opens the dialog box to set how many times to repeat PTZ cruise, and how many seconds between each preset point.</p> <div data-bbox="1402 1036 1885 1198" style="border: 1px solid gray; padding: 5px;"> <p>Repeat(1~999 times, 1000:infinite): <input type="text" value="1000"/></p> <p>Interval(3~1200 seconds): <input type="text" value="5"/></p> <p style="text-align: right;"><input type="button" value="OK"/> <input type="button" value="Cancel"/></p> </div>
	<p><b>Schedule for PTZ</b></p> <p>Click <b>Go</b> to start PTZ patrol schedule.</p>

## Exchange Streaming

If your IP cameras support dual stream, the NVR allows you to configure dual streaming in the Cameras Parameters page. Performance will be best if you set stream 1 at a higher resolution than stream 2. To switch streams, select the channel in the LiveView page and right-click to show the list.



**When Optimize is enabled:** the streaming type will be adjusted automatically for different display modes.

**When Optimize is disabled** - you can manually adjust streaming type, which will be memorized in different display modes.


## De-warp for fisheye cameras

Right-click on the video and choose a de-warp engine for cameras with fisheye.

- 1) Choose camera position.



- 2) Choose display mode.



## De-warp for Immersion Lenses

Right-click on the video and choose the de-warp engine for cameras with Immersion lenses.

- 1) Choose De-warping Method.




- 2) Choose Display Mode.




### Multi-NVR server

Add a multi-NVR server by clicking the search box. Enter the User Name and password for the NVR you wish to add to the local server. The NVR will appear. Click cameras up to 144 channels to add them into camera list. Click OK to add cameras or rescan to search for NVR again.



**Add Server** - NVRs can be manually added by entering URL or IP address, port, User Name and Password.




### Playback

Playback allows you to view recorded videos from cameras connected to your NVR. The NVR offers synchronized playback for up to four cameras, and easy steps to help you sort through the recorded videos quickly. You can view Playback video in full screen, and take and save snapshots during playback.

#### NOTE

LiveView and Playback features are **NOT** compatible with Mac OS X.



### Main Functions

#### Mute




Choose whether to play audio with videos.

#### Setting



To configure playback settings, click the button and choose the parameters for files to play and how they will be displayed on screen (OSD).

### Display mode



One Screen




Full Screen



Four Screens

### Video playback controls



- (1) **Pause** - temporarily stop the playback.
- (2) **Previous Image** - show the previous image or video.
- (3) **Slow motion** - play in slower speeds.
- (4) **Play** - play video file.
- (5) **Forward** - speed up playback.
- (6) **Next image** - show the next image or video.
- (7) **Rewind** - play backward.

### Play Speed Indicator

The play speed is displayed beside timetable.



### Scale bar

Use the scale slider to increase or reduce the time period for which you wish to check video files from timetable.



### Seek bar

The seek bar allows you to go to a specific point in a recording.



**Thumbnail in Playback** - The thumbnail function displays a snapshot of a specific moment when you move the seek bar within a recording. The thumbnail also provides related information, such as date, time and camera name.





### Digital zoom



### Snapshot




You can save an image from playback by clicking the Snapshot icon. Before taking a snapshot, choose a save location. Click the Settings icon  and choose a snapshot path. You can capture up to five consecutive frames as snapshots.




### De-warp for fisheye cameras

Right-click on the video and you can choose the proper de-warp engine for cameras with fisheye or Immervision Lens.


1. Choose the de-warp engine:



2. Choose the mounting type



3. Choose the display mode






### Change OSD (on-screen display) color and font size

1) Click **Setting** icon.



2) Click **Color**, select the OSD color and click **OK**.



3) Select font size from drop-down list and click **OK**.




4) The font size and color are changed on the playback screen.




## Video Playback

Before viewing recorded videos, click the **Setting** icon to set recorded videos for playback.



- 1) Select cameras from camera list and select up to four camera numbers to search recorded videos.




Once the camera is selected, a timeline will be shown on the timetable.




- 2) Please select the date the video was recorded. The date marked in blue has recorded video.




If there is an event recording in the specific date, the date will be marked as blue with a red stripe beside it.



You can also select a specific time period (start time to end time). Time is expressed as **hour:minute:second**. The default time period is from 00:00:00 to 23:59:59.



- 3) Select recording type. There are five types of video files: **Normal (Gray)**, **Event (Red)**, **Video Clip (Black)**, **Recovery (Blue)** and **Daylight saving time (Green)**. Default recording type is Normal.



Timetable will display the colors in a remote browser.



- 3) Click **Play** button.




### Frame by Frame Playback


- 1) Follow "Steps to Playback Videos" section above.
- 2) Click **Pause** button.
- 3) Click **Previous Image** or **Next Image** button.




### Export Files

The export function allows you to retrieve recorded video files from a server.


- 1) Before exporting files, choose a save location. Click  to choose a path to save the video file.
- 2) Select an AVI path where exported files and click **OK**.



- 3) Choose cameras and time ranges to export.


- 4) Press  to export the video file. Both NVRPlayer and NVRCheck will be exported with the video files.

- **NVRPlayer** is the player of NVR recording file.
- **NVRCheck** is a tool to verify the files were recorded on the NVR.



## Play Video Files Remotely

Accessing video files via Networking Sharing and FTP Service. You must enable Networking Sharing and FTP Service in *File Sharing Management* under *Disk Management* on the NVR Configuration page.




- The Device Name can be found in Network > Network Setup > Information on the Configuration page.



- Double-click on the device to log in with a User name and Password. If you haven't changed them, the User name and Password are "admin" and "admin."




- You will see two folders: Public and videodata1. Select videodata1 to check video files.




## Find my record video files with network sharing

- Go to the Network folder and find the NVR device name.




- Video files are organized chronologically by recording date. Five-minute video files are sorted chronologically in each folder. Select a video file to play.




### Find my record video files with FTP services


- Type the following address in the browser's bar: "ftp://<your NVR's IP address>" and press Enter on your keyboard.




- Log in with a User name and Password. If you haven't changed them, the User name and Password are "admin" and "admin." Click Log On.



- You will see a list of directories (folders). Select videodata1.



- 4) Video files are organized chronologically by recording date. Five-minute video files are sorted chronologically in each directory/folder. Select a video file to play.



# Configuration

You can configure **IP Camera**, **Recording & Event**, **Disk Management**, **Network**, **Management** and **System** from drop-down menus on the Configuration page.

## Camera Settings

Your NVR provides two options for adding cameras: Settings and UPnP Search.

**Camera Settings**

Adding Cameras

Settings

CH 1

Camera Name

IP Address  Port 80

Username  Password

Vendor **Linksys** Model

Streaming Path  RTSP port

Video Recording  Enable recording by default

UPnP Search

### Manually Adding Camera:

- 1) Enter a Camera Name, IP Address, Username, Vendor and Password.

**Camera Settings**

Adding Cameras

Settings

CH 1

Camera Name

IP Address  Port 80

Username  Password

Vendor **Linksys** Model

Streaming Path  RTSP port

Video Recording  Enable recording by default

- 2) If you select Generic RTSP or Generic MJPEG in the Vendor field, enter Streaming Path column with proper RTSP or MJPEG URLs. If Generic RTSP is selected, RTSP port should be filled out too.

**NOTE**

The most correct URLs should be provided from each camera vendors.

**Camera Settings**

Adding Cameras

Settings

CH 1

Camera Name

IP Address  Port 80

Username  Password

Vendor **Linksys** Model

Streaming Path  RTSP port

Video Recording  Default

UPnP Search

**Camera Settings**

Adding Cameras

Settings

CH 1

Camera Name

IP Address  Port 80

Username  Password

Vendor **Generic RTSP(H264)** Model

Streaming Path  RTSP port 554

Video Recording  Enable recording by default

Tip: If RTSP URL is rtsp://192.168.1.5/channel1. The streaming path is channel1.

UPnP Search

- 3) Click **Apply**.
- 4) All added cameras appear in Camera List.

**Camera List**

CH	Camera Name	IP Address	Port	Vendor	Model	Delete
1	cam1	192.168.1.10	80	Linksys	LCAM02360D	<input type="button" value="Delete"/>
2			80			
3			80			
4			80			
5			80			

## Adding Camera with UPnP Search

- 1) Click **UPnP Search** to find UPnP devices in your LAN.

The screenshot shows the 'Camera Settings' page with the 'Adding Camera' tab selected. Under the 'Settings' section, there are fields for Camera Name, IP Address, Username, Password, Vendor (dropdown), Model, Streaming Path, and RTSP port. A checkbox for 'Video Recording' is checked with the label 'Enable recording by default'. The 'UPnP Search' button is highlighted with a red box.

- 2) Available cameras will be displayed. Click **Add** to add the camera.

The screenshot shows the 'UPnP Device List' table with one entry: ID 1, IP Address 192.168.1.19, Port 80, Vendor Linksys, Model LCAM03360D, and MAC 00-22-F4-CE-47-DD. The 'Add' button is highlighted with a red box.

### NOTE

Your network camera must be UPnP enabled. Check with your camera supplier on how to enable UPnP.

- 3) Manually enter Camera Name, Username and Password and click **Apply**.

The screenshot shows the 'Camera Settings' page with manual entry fields highlighted by red boxes: Camera Name, IP Address (192.168.1.19), Username, and Password.

- 4) Once you have added all your cameras, click **Back** to return to the Camera Settings page and check your Camera List.

The screenshot shows the 'UPnP Device List' table with one entry. The 'Back' button is highlighted with a red box.

The screenshot shows the 'UPnP Device List' table with one entry. The 'Add' button is highlighted with a red box.

- 5) Users can refresh UPnP device list by clicking **Re-search**

The screenshot shows the 'UPnP Device List' table with one entry. The 'Re-search' button is highlighted with a red box.

## Delete

To delete a camera from the list, select the row and click **Delete**.

ID	Camera Name	IP Address	Port	Vendor	Model	Delete
1	cam1	192.168.1.19	80	Linksys	LCAM03360D	Delete
2			80			
3			80			
4			80			
5			80			




## Video Settings

Your NVR supports multi-stream monitoring and recording. You can modify settings such as video format, frame rate, resolution and video quality.

### Configure Camera Video Settings

The row of the camera you choose will be highlighted. The window below will appear with settings to configure multi-stream.



**Video Format** - Choose a video compression format for live view and recording: MPEG4, H.264 and MJPEG.

**NOTE**  
Video formats vary depending on the camera brands and models.

**Frame Rate** - Select frame rate from drop-down list. The network environment will influence frame rate of IP camera.

**Resolution** - Select resolution from drop-down list.

**Video Quality** - Select **VBR** (Variable Bit Rate) or **CBR** (Constant Bit Rate).

**Enable Audio** - Enable or disable audio recording function.

Ch	Camera Name	IP Address	Vendor	Model	Camera WebUI
1	cam1	192.168.1.19	Linksys	LCAM03160D	Go to Web
2					Go to Web
3					Go to Web
4					Go to Web
5					Go to Web

**Go to Web** - For advanced settings, click Go to Web to access your camera's Web configuration interface.

## Camera Status

Shows status of connection to NVR, recording status, framerate (fps), bitrate (Kbps).

No.	Camera Name	IP Address	Conn. Status	Rec. Status	Framerate(fps)	Bitrate(Kbps)
1	cam1	192.168.1.19	Connected	Recording	30 fps	4637.9 Kbps
2			-	-	0 fps	0 Kbps
3			-	-	0 fps	0 Kbps
4			-	-	0 fps	0 Kbps
5			-	-	0 fps	0 Kbps
						4637.9 Kbps

## Recording Settings

Recording & Event provides different modes and recording schedules for you to configure your IP camera.



**No Recording** - Recording will be disabled on all cameras.

**Event Recording** - Enables the scheduling of a time to record video. The schedule can be configured in the **Schedule** tab.



**Always Recording** - Select a camera or check **All**. Selected cameras will record video continuously.

**Your NVR provides two ways to delete recorded videos**

- **HDD Automatic Recycle:** Overwrites oldest video files automatically when saved data hits assigned threshold. Maximum threshold is 90%; minimum is 20%. For example, if you set the threshold at 70%, the oldest files on the HDD will be deleted when data stored is 70% of capacity.
- **Video Keeping Period:** Set a time period for keeping videos. For example, if the period is seven days NVR will automatically delete videos older than seven days.


**Schedule**

Define time ranges in **Event Recording** for all cameras.


- 1) Select a camera and set the schedule.



- 2) Choose start/end time and camera(s) to set a recording schedule. Click **Insert**.




- 3) A time bar shows the scheduled time for all cameras.




- 4) If you want to set more than one schedule, repeat process to insert more schedules for the same camera.
- 5) Click **Apply** to finish setting the schedule or **Cancel** to adjust the schedule.



**Delete** - Erase a specific time in a recording schedule by selecting the time in the schedule table for a camera and clicking **Delete**.



**Delete All** - Delete all scheduled recordings for a camera by selecting the camera from the Camera List, checking the Delete All box and clicking **Delete**.



## Event & Action Management

With Event & Action Management, you can arrange for the NVR to perform certain actions, including notifying you, when an event occurs with an IP camera.

### Event List

- **Disconnected** - The action will be triggered if the selected camera loses connection with the NVR.
- **Motion from Camera** - Your selected actions will be triggered once motion is detected.
- **Digital Input** - Your selected actions will be triggered once Digital Input is detected.
- **NVR event (Disconnected)** - If your NVR loses its network connection, Digital Output will be triggered.
- **NVR event (Recording Error)** - If your NVR fails to record, it will send you an email notification.
- **External HTTP Event** - Event could be triggered by external HTTP-in CGI command. You can define up to five different HTTP-in events. Set actions just like other events.

The format of external HTTP event CGI: `http://<NVR_IP>/login.cgi/cgi_main.cgi?cgiName=event_ipc.cgi&eventName=Defined_<int>`

- <NVR\_IP> is the IP of NVR that the command needs to be delivered to.
- <int> is defined for the number (1~5) of external HTTP-in events that need to be triggered.

### For example:


[http://192.168.1.245/login.cgi/cgi\\_main.cgi?cgiName=event\\_ipc.cgi&eventName=Defined\\_3](http://192.168.1.245/login.cgi/cgi_main.cgi?cgiName=event_ipc.cgi&eventName=Defined_3)

The CGI sends a message to the NVR with IP 192.168.1.245 and triggers external event #3.

## Actions List


Check an event type and click Add to create an action.

- **Send Email** - The NVR will send an email every 20 seconds during the event. So, if an event lasts one minute, your NVR will send three emails.




**Attached with the snapshot** - Email will be sent with snapshot of the event.

**Apply Options** - To select cameras to apply this action.



• **Digital Output**




**Buzzer** - Can be enabled to sound for up to 60 seconds.

**Digital Output1 and 2** - Supported by other digital outputs of the server and can be enabled for up to 60 seconds.

**Apply Options** - Select cameras to apply this action.

- **User Defined Action** - Send a specific HTTP command when an event is triggered, allowing you to manage devices such as power controller, fire/smoke protection device.

• **Event Trigger Record**



**Video Clip** - A video clip will be sent by email. In the Advanced tab, you can change the number of seconds before and after the event triggers that you want to be included in the clip.

**Apply Options** - Select cameras that you want to record video clips at the event trigger.

**Advanced**



**Action Triggered Interval** – Set the amount of time that the NVR must wait between triggered events. Set an interval time during each events are triggered in sequence.


**Video Clip and Recording Settings** - You can change the number of seconds before and after the event trigger that you wish included in the clip. Video clips can include as many as 300 seconds before the event is triggered, and up to 300 seconds after the event ends.

**Event Triggered with Audio** - You may record audio only when an event is triggered. When the event stops, the audio will be disabled again automatically.

### Schedule

Set up event detection for a certain time period.

- 1) Enable the event detection.



#### NOTE

Event schedules automatically start in "always" mode.

- 2) Go to the Schedule tab.




- 3) Select Day or Week schedule.




### By Day

1. Select the camera.
2. Designate the time period.
3. Click Insert.
4. Designated duration is displayed.
5. Designated duration is shown on chart.
6. Press **Apply**.



### By Week


1. Select the Week for the specific recording schedule.
2. Designate the time period.
3. Select the camera and Click Insert.
4. The designated duration is displayed.
5. The designated duration is shown in chart.
6. Click **Apply**.



4) Click Apply to apply the settings.

**Remove event schedule**

- 1) Designate the time period on chart by clicking on it.
- 2) Click **Delete**.




**Remove all event periods in one camera**

- 1) Click any period of the camera.
- 2) Check Delete All.
- 3) Click **Delete**.

## E-Mail Settings

### Setup



**SMTP Server Address** - Enter the Server Address of the SMTP server.

**From** - Specify sender's email address in the Sender field.

**Subject** - Enter the email subject.

**Message** - Enter the email content.

**Authentication** - Depending on the mail server, SMTP Server provides three types of authentication. Select PLAIN, LOGIN, or LOGIN with TLS.

**Username** - Specify username.

**Password** - Specify user password.

**Send Test Mail** - Test your email settings.

### Send to List


**Add Contact** - Add contact you like the email to be sent.

**Email Send to List** - Display the contact list.



## Disk Management


Disk Information provides details of the hard disk drive: Slot Number, HDD Model, Serial No., Capacity and Status.



### Creating a new RAID Disk


1) Click **Create** tab to create a New RAID Disk.




2) The selected hard disk drive will be marked in blue. Click  to move the hard disk drive into the Assigned HDDs field.



3) The selected hard disk drive in Assigned HDDs field will be marked in blue.



4) You can choose from four types of disk configuration. Choose a disk configuration and click **Apply** to configure the RAID disk.



<b>Big Drive (Linear)</b>	Big Drive is a collection of hard disk drives and does not provide any RAID protection. The data are written to the disks continuously.
<b>Performance (RAID0)</b>	RAID0 combines two or more hard disk drives to function as one larger volume. Data are written to the hard disk drives without any parity information. Total storage capacity is the sum of all hard disk drives.
<b>Fault Tolerant (RAID1)</b>	A RAID1 array requires two hard disk drives. RAID1 provides disk mirroring by duplicating the data between two hard disk drives.

**Fault Tolerant (RAID5)** A RAID5 array requires a three or more hard disk drives. Data are striped in all hard drives in a RAID5 array, and parity information is stored in each drive. If a hard disk drive fails, the array enters degraded mode. The data can be rebuilt from other member drives after installing a new drive to replace the failed one.

- 5) Configuration progress is tracked in the Disk Information window. When formatting progress reaches 100%, configuration mode switches to "create swap."

**NOTE**  
Don't turn off the server or unplug any hard drives when RAID Disk configuration is in process.



- 6) When progress reads, "none," the RAID disk configuration is complete. After the RAID disk is created, RAID Disk List shows details about the disk: RAID Name, RAID type, Capacity, Status, Action State, Background Activity, Estimated Time and Progress.



## File System Management

The filesystem information will show the volume of the RAID as below. Filesystem is a way to organize data you will need after a program is terminated. It provides procedures to store, retrieve and update data, as well as to manage the available space on the device.



## File Sharing Service

Arrange data transmission service including **Windows Networking** and **FTP service**.

### Information

Once the hard disk is installed, the filesystem will show status as below. **Enable** or **Disable** a sharing service to turn On/OFF Windows Networking and FTP service.



When a service is enabled, you can open dialog windows in a browser or Windows Explorer using the URL Address.





## Network Sharing

In *Network Sharing* tab, you can enable or disable file sharing services, or change Device Description and Domain or Workgroup Name.

## FTP Server

You can enable or disable the FTP Server and change the port. Click **Apply** to save any changes.

## Network Setup

### Information

Network information displays your network configuration: Device Name, IP Address, Subnet Mask, Default Gateway IP Address, and Primary DNS.

## Network

You can rename the device and decide the Network Connection Type

- **Obtain an IP address automatically**

Obtain an available dynamic IP address assigned by a DHCP server. Your NVR will automatically obtain an available dynamic IP address from the DHCP server when connecting to the LAN.

- **Specify an IP address**

If no DHCP server exists in the networking environment, the IP address will be given as 192.168.1.245. It should be sufficient in most network environments, and users can maintain the default IP address or alter IP address in this page. However, it's recommended to set a different IP address if there is more than one NVR in the network.

## Port

You can configure an HTTP port here. The default port is 80.

## Network Management

### IP Filter

- 1) Select **Allow Access** or **Deny Access** to specified IP addresses.

Network Management

Access Filter List

IP Filter

Options:  Allow Access  Deny Access

IP Range

No.	IP Address	Access	Delete

Apply Cancel

- 2) Enter an IP address range to allow or deny access.

Options:  Allow Access  Deny Access

IP Range: 192.168.1.10 to 192.168.1.20

Add

### UPnP

UPnP field displays UPnP name. You can enable or disable UPnP search.

Network Management

Access Filter List

UPnP

Setting

UPnP Name: 06-2010Tablet2w

Apply Cancel

## DDNS

DDNS links a domain name to an IP address, allowing you to easily access your cameras even with a changing IP address. Your NVR is compatible with two DDNS service providers: **DynDNS** and **No-IP**.

DDNS

Settings

Provider List:  DynDNS  no-ip

Registered Info:

Username: (Max. length: 128 characters)

Password: (Max. length: 64 characters)

Host Name: (Max. length: 128 characters)

Apply Cancel

### NOTE


Before utilizing this function, please apply for a dynamic domain account from a DDNS provider.

## User Management

Multiple users can access the NVR simultaneously. The built-in Administrator account (user name "admin" and password "admin") creates other user accounts. Administrator has the highest privilege compared to Power User and User. And Power User and User can be given different privileges for live view and playback of different channels.

### Create Users

- 1) Enter a username and password.
- 2) Select the users from the Group drop-down list.
- 3) Check LiveView Access and Playback access.
- 4) Click **Apply**.




After the Power User is created, Users List will display the information as below.

### Modify Users

- 1) Select a user to modify. The selected account will be highlighted.

No.	Name	Group	LiveView	PTZ	Multi Server	Playback
1	Catherine	power user	1,2,3,4,5	0	0	1,2,3,4,5

- 2) Modify the user settings



- 3) Click **Apply**.

### Delete Users

To delete the user account, click **Delete**.

No.	Name	Group	LiveView	PTZ	Multi Server	Playback	Delete
1	Catherine	power user	1,2,3,4,5	0	0	1,2,3,4,5	Delete
2	Hannah	user	1,2,3,4	0	0	1,2,3,4,5	Delete

### Change Password

Each NVR comes with a built-in admin account with password “admin.” You should change the password upon the initial login. Select an account from the Username drop-down list to change the password.

- 1) Enter a new password in the New Password field
- 2) Enter it again in the Retype Password field.
- 3) Click **Apply**.



### Log System

Log System records the activity on the NVR, and provides basic information for troubleshooting. There are six types of logs: Hardware Log, NVR Log, Event Log, Current User, History of User and File Access Log.

#### Hardware Log

Log information: RAID creation, RAID deletion, RAID modification, CPU, buzzer, fan, system, sensor and USB.

**Log System**

Hardware Log | NVR Log | Event Log | Current User | History of User | File Access Log

Date: All | Level: All | Page: 1 | Number of Displays: 20 | Save

Date & Time	Level	Message
2013/12/26 14:41:58	notice	[HW] enable buzzer notice
2013/12/26 14:41:58	notice	[HW] enable fan control
2013/12/26 14:41:58	info	[HW] System is starting to work.
2013/12/27 11:44:54	notice	[HW] enable buzzer notice
2013/12/27 11:44:54	notice	[HW] enable fan control
2013/12/27 11:44:54	info	[HW] System is starting to work.
2013/12/26 17:02:20	notice	[HW] RAID deleted.
2013/12/26 18:58:13	notice	[HW] RAID creation finished.
2013/12/26 18:58:51	notice	[HW] RAID creation started.
2013/12/26 18:20:13	notice	[HW] RAID deleted.
2013/12/26 16:07:53	notice	[HW] RAID creation finished.
2013/12/26 16:05:30	notice	[HW] RAID creation started.
2013/12/26 15:48:47	notice	[HW] HDD at slot 2 is attached.
2013/12/26 15:03:01	notice	[HW] enable buzzer notice
2013/12/26 15:03:01	notice	[HW] enable fan control
2013/12/26 15:03:01	info	[HW] System is starting to work.
2013/12/26 11:02:40	notice	[HW] system poweroff trigger by power button.
2013/12/26 11:02:36	notice	[HW] system poweroff trigger by power button.
2013/12/26 10:58:06	notice	[HW] system poweroff trigger by power button.
2013/04/03 19:29:03	notice	[HW] system poweroff trigger by power button.

### Event Log

Log information: Camera is connected, Camera is disconnected, Digital Input, Motion detected and Storage usage is out of limit, etc.

**Log System**

Hardware Log | NVR Log | Event Log | Current User | History of User | File Access Log

Date: All | Level: All | IP Cam: All | Page: 1 | Number of Displays: 20 | Save

Date & Time	Level	Number	Message
2013/12/26 18:52:52	notice	1	[Event] Camera is disconnected.

### Current User

Log information: users logged in to the NVR with an IP address.

**Log System**

Hardware Log | NVR Log | Event Log | Current User | History of User | File Access Log

Date & Time	Account	IP Address	Message
2013/12/26 16:14:17	admin	192.168.1.144	[CurUSER] Access nrg_management_log_currentuser.htm

### History of User

Log records activity of any user who has logged in to the NVR.

**Log System**

Hardware Log | NVR Log | Event Log | Current User | History of User | File Access Log

Date: All | Level: All | Page: 1 | Number of Displays: 20 | Save

Date & Time	Level	Account	IP Address	Method	Message
2013/12/26 16:20:26	info	admin	192.168.1.144	HTTP	[USER] Account [Hannan] is configured.
2013/12/26 16:16:13	info	admin	192.168.1.144	HTTP	[USER] Account [Hannan] is created.
2013/12/26 15:15:29	info	admin	192.168.1.144	HTTP	[USER] Account [Hannan] is deleted.
2013/12/26 15:15:11	info	admin	192.168.1.144	HTTP	[USER] Account [Hannan] is created.
2013/12/26 15:14:51	info	admin	192.168.1.144	HTTP	[USER] Account [Hannan] is deleted.
2013/12/26 15:14:36	info	admin	192.168.1.144	HTTP	[USER] Account [Hannan] is created.
2013/12/26 15:14:17	info	admin	192.168.1.144	HTTP	[USER] Login
2013/12/26 15:14:17	info	admin	192.168.1.144	HTTP	[USER] Login
2013/12/26 16:03:38	info	admin	192.168.1.144	HTTP	[USER] Account [Catherine] is created.
2013/12/26 15:25:05	info	admin	192.168.1.144	HTTP	[USER] Login
2013/12/26 15:25:05	info	admin	192.168.1.144	HTTP	[USER] Login
2013/12/26 15:09:15	info	admin	192.168.1.144	HTTP	[USER] Enable Windows networking service.
2013/12/26 15:09:13	info	admin	192.168.1.144	HTTP	[USER] Enable FTP service.
2013/12/26 15:07:32	info	admin	192.168.1.144	HTTP	[USER] Disable FTP service.
2013/12/26 15:07:30	info	admin	192.168.1.144	HTTP	[USER] Disable Windows networking service.
2013/12/26 14:58:22	info	admin	192.168.1.144	HTTP	[USER] Enable FTP service.

### NVR Log

Log information: time zone, daylight, system, firmware upgrading, configuration IP, recording files export, and storage.

**Log System**

Hardware Log | NVR Log | Event Log | Current User | History of User | File Access Log

Date: All | Level: All | Page: 1 | Number of Displays: 20 | Save

Date & Time	Level	Account	IP Address	Message
2013/12/26 14:41:58	info	SYSTEM	Localhost	[NVR] System is ready for starting up.
2013/12/27 18:37:32	notice	SYSTEM	Localhost	[NVR] System is shutting down.
2013/12/27 11:44:54	info	SYSTEM	Localhost	[NVR] System is ready for starting up.
2013/12/27 11:35:09	notice	SYSTEM	Localhost	[NVR] System is shutting down.
2013/12/26 15:03:01	info	SYSTEM	Localhost	[NVR] System is ready for starting up.
2013/12/26 15:51:52	notice	SYSTEM	Localhost	[NVR] Firmware upgrading.
2013/12/26 14:55:28	notice	SYSTEM	Localhost	[NVR] Firmware upgrading.
2013/12/26 13:19:28	notice	SYSTEM	Localhost	[NVR] Firmware upgrading.
2013/12/26 12:33:13	info	SYSTEM	Localhost	[NVR] The IP is been changed - 192.168.1.245-
2013/12/26 11:02:34	info	SYSTEM	Localhost	[NVR] Storage is not ready! Unable to handle temp file.
2013/12/26 10:46:07	info	SYSTEM	Localhost	[NVR] The IP is been changed - 192.168.1.11-
2013/12/26 10:46:10	info	SYSTEM	Localhost	[NVR] The IP is been changed - 192.168.1.11-
2013/12/26 10:41:25	info	SYSTEM	Localhost	[NVR] Storage is not ready! Unable to handle temp file.
2013/12/26 10:36:54	info	SYSTEM	Localhost	[NVR] the IP is been changed - 192.168.1.245-
2013/03/12 15:40:06	notice	SYSTEM	Localhost	[NVR] System is shutting down.
2013/03/12 12:37:38	notice	SYSTEM	Localhost	[NVR] System is shutting down.
2013/03/11 18:44:22	notice	SYSTEM	Localhost	[NVR] System is rebooting.
2013/03/11 18:06:56	notice	SYSTEM	Localhost	[NVR] System is rebooting.
2013/03/11 11:47:22	notice	SYSTEM	Localhost	[NVR] Firmware upgrading.
2013/03/09 11:23:08	info	SYSTEM	Localhost	[NVR] The system time is configured.

## File Access Log

Log records access to your NVR through methods other than HTTP (SAMBA or FTP).

### Log System

Log System						
Hardware Log	NVR Log	Event Log	Current User	History of User	File Access Log	
Date: All   Level: All   Page: 1   << < > >>   Number of Displays: 20   Save						
Date & Time	Level	Account	IP Address	Method	Message	Status
2013/12/30 15:13:38	info	admin	192.168.1.144	FTP	[SYSCON] Login	Pass
2013/12/30 15:13:28	info	admin	192.168.1.144	FTP	[SYSCON] Login	Pass
2013/12/30 15:02:22	info	admin	192.168.1.144	SAMBA	[SYSCON] Login	Pass
2013/03/06 16:09:29	info	admin	192.168.1.4	SAMBA	[SYSCON] config.def	Access
2013/03/06 16:09:28	info	admin	192.168.1.4	SAMBA	[SYSCON] config.def	Access
2013/03/06 16:09:25	info	admin	192.168.1.4	SAMBA	[SYSCON] Login	Pass

## Export log files

Users can export and save log files from the Log System page by clicking.

Log System						
Hardware Log	NVR Log	Event Log	Current User	History of User	File Access Log	
Date: All   Level: All   Page: 1   << < > >>   Number of Displays: 20   <b>Save</b>						
Date & Time	Level	Account	IP Address	Method	Message	Status
2013/12/30 14:41:58	notice				[HW] enable buzzer notice.	
2013/12/30 14:41:58	notice				[HW] enable fan control.	

## Back Up and Restore

### Back Up Configuration

Select Volume and Folder, and specify the File Name to save configuration as a configuration (.cfg) file. Back up Configuration will just save Camera Setting, Recording Settings, Event & Action Settings, E-Mail settings, and Server Settings.

#### NOTE

The configuration file is saved in your NVR's Public folder. You can access the folder with Windows Networking or FTP service.

**Back Up and Restore**

Back Up | Restore

---

**Back Up Configuration**

Volume:

Folder:

File Name: .cfg

Notice: Save configuration will just save Camera Settings, Recording Settings, Event & Action Settings, E-Mail Settings, and Server Settings.

Apply | Cancel

### Restore Configuration and Factory Default

Restore Configuration can duplicate settings from one NVR to another without a manual configuration.

- 1) Select "Reset to Factory Default" to reset the NVR to its original state or select "Restore" to restore the settings from configuration file.
- 2) Leave volume and folder default settings.
- 3) Enter the name of the configuration file to restore.

#### NOTE

The configuration file needs to be located in NVR's public folder before you can restore it. You can access the folder with Windows Networking or FTP service.

- 4) Click **Apply**.

**Back Up and Restore**

Back Up | Restore

---

**Restore Configuration**

Load Types:  Reset to Factory Default |  Restore

Volume:

Folder:

File Name: .cfg

Notice: Load configuration will just load Camera Settings, Recording Settings, Event & Action Settings, E-Mail Settings, and Server Settings.

Apply | Cancel

## Data Backup

You can preset a quick backup of the most recent duration and channels to back up on Remote Web Browser. This will save the latest video files locally. When set, all you need to do is connect a USB device to the NVR (front panel backup area) and press and hold the BACKUP button above the USB port for three seconds.

During the backup process, the USB LED indicator will blink blue. When the backup completes, the blue light will fade.

### NOTE

- USB device format must be FAT32 file system.
- NVRPlayer and NVRCheck will be saved with the video files.
- **NVRPlayer** is the player of NVR recording file.
- **NVRCheck** is a tool to verify the files were recorded on the NVR.

## Backup Settings



**Hardware Backup Button** - Enabled or disable for security concerns.

**Back Up Video for Last** - Set a maximum of days and hours to back up the latest video files.


**Select Channel to Back Up** – Choose cameras or check All.

## Operating Data Backup

When the USB device is ready, the USB Storage Information screen will show: Ready, and the USB LED indicator will be blue.



While the backup is in progress, the USB Storage Information screen will show: Working, and Information: Copying: ...files.



To delete the current data on your USB drive, click Format.



## Device Information

### System Information

The System Information tab shows Product Model, Firmware Version, NVR Address, Operating System and Network Adapter.



**Locate** - Click Find My Device, and the NVR buzzer will sound for three seconds to help you locate your NVR.

### Hardware Monitor

The Hardware Monitor tab shows Temperatures and Fan Speed.




## System Upgrade

- 1) Download the latest firmware file and save to a local computer.
- 2) Press Browse and navigate to where you saved the firmware file.



- 3) Select the file, and click Upgrade.



- 4) When the upgrade is finished, your NVR will reboot.
- 5) Go to Device Information from the System drop-down list and check NVR firmware version.



## Date & Time

### Setup

Configure your device's date and time. You can have the NVR automatically set date and time with NTP server or you can configure it manually. To have the NVR set date the time, click the Time Zone tab and choose the time zone of your area.



### NOTE

Verifying and adjusting current local time and daylight saving time will help you avoid the following errors:

- Incorrect display time for playback videos.
- Inconsistent display time of event logs and when they actually occur.

### Time Zone

Set the time and date for your time zone, and choose whether to automatically adjust for daylight saving changes.



### Built-in NTP server in NVR

Your NVR allows client devices to synchronize with the time clock. This helps to maintain a consistent time schedule in your surveillance system. The built-in NTP server address is your NVR's IP address.



Settings

Time: 20 Dec 2013 17:54:39

Time Zone: (GMT+08:00)Taiwan

Automatically adjust clock for Daylight Saving Time

NTP Built-in Server: 193.168.1.245

Apply Cancel

## Buzzer

Enabled or disabled to set the Sound Alert.

### NOTE

To stop the buzzer sound when it occurs, press the BACKUP button on the front panel of your NVR for one second.



Buzzer

Alert Setup

Settings

Sound Alert:  Enabled  Disabled

Apply Cancel

## Reboot & Shutdown

Select Reboot to restart the NVR or select Shutdown to turn off the NVR.



Reboot & Shutdown

Reboot & Shutdown

Options

Reboot

Shutdown

Apply Cancel



# Specifications

## Model No.: LNR0208C

### Hardware

#### CPU

Processor Marvell

#### General

Memory:	1GB
HDD capacity	Up to 8TB (storage capacity per HDD up to 4TB)
HDD tray	2 x hot-swappable and lockable tray with K-Lock security slot for theft prevention
LAN port	1 x Gigabit RJ-45 Ethernet port
LED Indicators	HDD 1, HDD 2, eSATA, LAN
USB connectors	3 x USB 2.0: One in front for video backup, two in back are reserved for future enhancement
External eSATA	2 x eSATA ports
Buttons	Power, USB backup
DI/DO	4 in, 2 out
Alarm buzzer	System Warning
Form Factor	Tower
Power supply	External power adaptor, 60W Input: 100-240V
Power consumption	Operation: 15.9~20.8W (With 2 x 500GB HDD installed and in RAID 1 building process)

### Environment

Operating temperature	0°C ~ 40°C
Operating humidity	0% ~ 95% R.H
Build-in fans	1 x quiet cooling fan

### Compliance Information

FCC/IC	FCC/IC
CE	CE

### Major features list

Supported Channels	Up to 8
Video Compression (Depending on the camera)	H.264/MJPEG/MPEG-4
Maximum Throughput	150Mbps
Disk Management	JBOD/Linear, RAID0, RAID1 and RAID5
Event Management	Connection lost, Motion detection, External HTTP, Digital Input
Action Management	Event recording, E-mail notification, Digital Output, User-defined Action
Services	SMB/CIFS and FTP
Video Backup	USB Port
Remote LiveView	Y
Remote Playback	Y
Video Recording	Y
System Log	Y
User Management	Y
ONVIF Supported	Y

## Dimensions

Unit Dimension	246.1(D) x 114.97(W) x 164.94(H) mm 9.69(D) x 4.53(W) x 6.49(H) inch
Unit Weight (kg)	2.09kg

### NOTE

- For regulatory, warranty, and safety information, see the enclosed CD or go to [Linksys.com/business](https://www.linksys.com/business)
- Documentation is subject to change without notice

Visit [linksys.com/support](https://linksys.com/support) for award-winning technical support

© 2014 Belkin International, Inc. and/or its affiliates. All rights reserved. BELKIN, LINKSYS and many product names and logos are trademarks of the Belkin group of companies. Third-party trademarks mentioned are the property of their respective owners.

8820-01868 Rev. A00